



## LAYOUT AND CONNECTION POSITION DOUBLE JACKET FD-MK



L90



## DOUBLE JACKET FD-MK

| Capacity<br>liter | Tank- $\varnothing$<br>mm | Version | Connection position | Layout | Surface<br>m <sup>2</sup> | Order No.<br>mounted |
|-------------------|---------------------------|---------|---------------------|--------|---------------------------|----------------------|
| 6,000             | 1,600 / 2,200             | 1       | B1                  | L90    | 5.6                       | 1B1                  |
| 7,400             | 1,800 / 2,400             | 1       | B1                  | L90    | 6.2                       | 1B1                  |
| 10,000            | 2,000 / 2,600             | 1       | B1                  | L90    | 6.9                       | 1B1                  |
| 12,000            | 2,000 / 2,800             | 1       | B1                  | L90    | 7.0                       | 1B5                  |

